

Combination Boards Assembly & Installation Guide

Instructions:

- Remove 2no. screw from aluminium frame section of board with aluminium H section connection strip attached (one directly above connector strip and one below)
- Butt the two boards together ensuring the protruding plastic ends fit into the open ends of the aluminium trim on the opposite board
- Replace the 2no. screws back into the trim
- Using a 7mm drill bit, rawl plugs and screws (included) attach the board to the wall
- Use the grey caps to cover the fixings